

MID-HUDSON Cable

Mid-Hudson TV **QUICK SET UP**

My Stream from Mid-Hudson Cable



Find us online
mhcable.com

Table of Contents

1

AMAZON FIRE STICK	3
Requirements	4
Setup	5
App Install	6
Sign-in with Mid-Hudson Credentials	7

2

ROKU	3
Requirements	4
Setup	5
App Install	6
Sign-in with Mid-Hudson Credentials	7

3

APPLE TV	8
Requirements	9
Setup	10
App Install	11
Sign-in with Mid-Hudson Credentials	12

4

GOOGLE CHROMECAST	13
Requirements	14
Setup	15
App Install	16
Sign-in with Mid-Hudson Credentials	17

Amazon Fire Stick

SETUP INSTRUCTIONS



Fire Stick Requirements

This guide will show you how to set up Amazon FireStick for the first time.


The steps work on all Fire TV devices including FireStick 2nd/3rd Gen, Fire TV Stick Lite, FireStick 4K (Max), New FireStick 4K, New FireStick 4K Max, and Fire TV Cube.

A Compatible TV: Ensure you have, at a minimum, an HDTV (720p or higher) equipped with an HDMI port to utilize the Fire Stick

Internet Connection: The Fire Stick lacks its own internet connectivity. It is necessary to link your Fire Stick to your Mid-Hudson Cable WiFi connection.

Amazon Account: Last but not least, you'll need an Amazon account to register your Fire Stick. Amazon accounts are free and no credit card is required. Register for one at amazon.com

All hardware and software support beyond the Mid-Hudson TV app for the Fire Stick is through the manufacturer.




Fire Stick Setup

MID-HUDSON
My Stream




Unboxing

Unboxing your Firestick you will find the Firestick with HDMI connection, remote with AAA batteries, HDMI extension, USB to micro-USB power cable, USB power adapter.




Connect the Fire Stick

Plug the USB adapter into a wall outlet or power strip. Then plug the USB cable in the power adapter. Plug the micro-USB, smaller plug end, into the port on the side of the Firestick. (Please do not use the USB port on your TV) On your television, select an empty HDMI port and using the HDMI extension, plug it into your TV.




TV Source

On your TV remote find the input or source button and select the HDMI port you plugged the Firestick into on your TV and you will see the FireTV loading screen.



Pair the Remote

Insert the AAA batteries into the remote. The remote should automatically pair up with the Fire Stick.



Connect to Wifi

Your Fire Stick will now scan for your WiFi network. Choose your network and enter your password (if required) to connect.




Amazon Account

Follow the on-screen prompts to log into your Amazon account or create a new, free Amazon account.

MID-HUDSON
My Stream


Fire Stick

App Install



Home Screen

From the home screen, scroll to the app list icon.



Launch the App Store

Select the Appstore to open it.



Install the Mid-Hudson TV App

Search the Appstore for **Mid-Hudson TV**.

Select and download the app.

Once downloaded go back to the app list and scroll down to the Mid-Hudson My Stream Icon.



Quick Access

You can press this button on your remote and select Move to front which moves the Mid-Hudson TV app to the top menu bar for quicker access.

Fire Stick Sign-In

Launch the **Mid-Hudson TV App** and at the login screen please use the **Name** and **Password** provided when you signed up.

For Device Name please use something similar to Livingroom FireTV, defining the location of your device. This way if you have more than one in your home or business, we can identify it for support purposes.

Enjoy!



Roku

SETUP INSTRUCTIONS



Roku Requirements

This guide will show you how to set up Roku for the first time.

The steps work on all Roku devices including the Roku Express, Roku Express 4K, Roku Streaming Stick+, Roku Streaming Stick 4K and Roku Streambar.

A Compatible TV: Ensure you have, at a minimum, an HDTV (720p or higher) equipped with an HDMI port to utilize Roku.

Internet Connection: The Roku lacks its own internet connectivity. It is necessary to link your Roku to your Mid-Hudson Cable WiFi connection.

Roku Account: Last but not least, you'll need a Roku account to register your Roku. Roku accounts are free and no credit card is required. Register for one at roku.com

All hardware and software support beyond the Mid-Hudson TV app for Roku is through the manufacturer.




Roku Setup

MID-HUDSON
My Stream




Unboxing

Unboxing your Roku you will find the Roku Stick/Base with HDMI connection, remote with AAA batteries, USB power cable, USB power adapter.



Connect Roku to your TV

Connect your Roku player using the correct HDMI cable, or connect your Streaming Stick directly to an open HDMI port on your TV. Use the power adaptor (or USB power cable and power adaptor) to connect your Roku streaming device to a wall outlet.



TV Source

On your TV remote find the input or source button and select the HDMI port you plugged Roku into on your TV and you will see the Roku loading screen.



Pair the Remote

Insert the AAA batteries into the remote. The remote should automatically pair up with the Roku. Follow the instructions on your TV screen.



Connect to Wifi

Go into Settings and then choose your wireless network from the list of available networks and enter your password.





Roku Account

Activate your streaming player by using your computer or smartphone to link a Roku account.

MID-HUDSON
My Stream


Roku

Channel Install




Home Screen

From the home screen, scroll up or down and select Streaming Channels to open the Channel Store.




Launch the Channel Store

In the Search Channels area, enter **Mid-Hudson TV**.



Install Mid-Hudson TV Channel

Select **Add Channel** to install **Mid-Hudson TV** on your Roku device. **Mid-Hudson TV** will be added to the list of channels under Home on the main screen.



Quick Access

Using the Star button on the remote, you can move the Mid-Hudson TV channel using the directional pad and press the OK button on your remote when you are satisfied with the new location.

Roku Sign-In

Launch the **Mid-Hudson TV Channel** and at the login screen please use the **Name** and **Password** provided when you signed up.

For Device Name please use something similar to Livingroom RokuTV, defining the location of your device. This way if you have more than one in your home or business, we can identify it for support purposes.

Enjoy!



Apple TV

SETUP INSTRUCTIONS



Apple TV Requirements

This guide will show you how to set up Apple TV for the first time.

The steps work on all Apple TV devices including the Apple TV HD and Apple TV 4K.



A Compatible TV: A high-definition or 4K TV with HDMI

HDMI Cable: An HDMI cable to connect Apple TV to your TV (for 4K HDR, you may require a compatible Ultra High Speed HDMI cable, sold separately)


Internet Connection: Apple TV lacks its own internet connectivity. It is necessary to link your Apple TV to your Mid-Hudson Cable WiFi connection.

Apple ID: An Apple ID for purchasing and renting, downloading apps from the App Store, and using Home Sharing.

All hardware and software support beyond the Mid-Hudson TV app for Apple TV is through the manufacturer.

Apple TV Setup

MID-HUDSON
My Stream




Unboxing

Unboxing your Apple TV you will find the Apple TV unit with the Siri remote, power cord and lightning to USB cable.




Connect Apple TV

Connect one end of an HDMI cable to the HDMI port on your Apple TV, then connect the other end to the HDMI port on your TV. Connect one end of the power cord to the power port on your Apple TV and the other end to a power outlet.



TV Source

On your TV remote find the input or source button and select the HDMI port you plugged Apple TV into on your TV and you will see the Apple TV loading screen.



Language & Siri

Choose your language on screen and turn on Siri. You can automatically complete the setup with your iPhone or If you don't want to set up your Apple TV with your iPhone, choose Set Up Manually.



Connect to Wifi

Follow the onscreen steps on your Apple TV to connect to your home Wi-Fi network (if setting up manually).




Apple TV Account

Sign in with your Apple ID. If you don't have an Apple ID, you can create one at apple.com.

MID-HUDSON
My Stream


Apple TV

App Install



Home Screen

From the home screen, scroll till you find the search button and select it.



Search

Search for **Mid-Hudson TV**. The Mid-Hudson TV app will show up below.



Install Mid-Hudson TV Channel

Select **Mid-Hudson TV** on your Apple TV screen and click Open. **Mid-Hudson TV** will be added to the list of apps under Home on the main screen.



Rearrange Home Screen

Navigate to the Mid-Hudson TV app, press and hold the clickpad center then select Edit Home Screen. Drag the Mid-Hudson TV app to a new location on the Home Screen. Then press the clickpad center again to save the arrangement.

Apple TV Sign-In

Launch the **Mid-Hudson TV App** and at the login screen please use the **Name** and **Password** provided when you signed up.

For Device Name please use something similar to Livingroom AppleTV, defining the location of your device. This way if you have more than one in your home or business, we can identify it for support purposes.

Enjoy!



Google Chromecast


SETUP INSTRUCTIONS



Chromecast Requirements

This guide will show you how to set up Google Chromecast for the first time.

The steps work on all Chromecast devices.



A Compatible TV: A high-definition or 4K TV with HDMI

Internet Connection: The Roku lacks its own internet connectivity. It is necessary to link your Roku to your Mid-Hudson Cable WiFi connection.


Google Home App: Download and install the Google Home app on your phone or device. If you're using an Android device, you can find the app in the Google Play Store, or in the Apple App Store if you're using an iPhone or an iPad.

Google Account: Last but not least, you'll need a Google account to use your Chromecast. Google accounts are free and no credit card is required. Register for one at [google.com](https://www.google.com)

All hardware and software support beyond the Mid-Hudson TV app for Chromecast is through the manufacturer.


Chromecast Setup

MID-HUDSON
My Stream




Unboxing

Unboxing your Chromecast you will find the Chromecast unit with the voice remote, two AA batteries, power cord and power adapter.




Connect Chromecast

Plug your Chromecast into your TV's HDMI port and into a power supply. First, plug the USB cable into your Chromecast, and then plug your Chromecast into an HDMI port on your TV.




TV Source

On your TV remote find the input or source button and select the HDMI port you plugged Chromecast into on your TV and you will see the Chromecast welcome screen.



Google Home Setup

Open the Google Home App on your phone or device and follow the on-screen instructions. First, tap Get Started. Then, sign in to a Google account or create one if you don't have one already.



Setup New Device

Continue the Google Home setup to create a new device and discover your Chromecast. Once discovered, name your Chromecast device and complete the setup.




Connect to Wifi

Connect Chromecast to your WiFi. Make sure you connect your phone or tablet to the same WiFi network as your Chromecast.


MID-HUDSON
My Stream

Chromecast **App Install**



From the Remote

Press and hold the Google Assistant button on the remote and say **Mid-Hudson TV**.




From the Home Screen

Scroll to **Apps** on the top of the home screen and click it.



Install Mid-Hudson TV App

Search for **Mid-Hudson TV** on the Apps screen. Select and install the **Mid-Hudson TV** app.



Quick Access

Navigate to the Mid-Hudson TV app, press and hold the clickpad center until the menu options appear, then select **Move**. Move the Mid-Hudson TV app to a new location on the Home Screen then tap **press to confirm**.

Chromecast Sign-In

Launch the **Mid-Hudson TV App** and at the login screen please use the **Name** and **Password** provided when you signed up.

For Device Name please use something similar to Livingroom ChromecastTV, defining the location of your device. This way if you have more than one in your home or business, we can identify it for support purposes.

Enjoy!

